

LGB Aster 20922 Garratt «Drakensberg»

Flachband Lok-Tender Original

T1	Bez	T2	Bez
1	Schiene A M1	1	Schiene B M1
2	Schiene A M1	2	Schiene B M1
3	Motor A M1	3	Motor B M1
4	Motor A M1	4	Motor B M1
5	Fire + Front Light + Smoke Plus	5	Front Light
6	Motor A Ma	6	Motor B M1
7	Fire + Smoke Minus	7	Cabine
8	Reed 2 (not used)	8	not used
9	Reed 1 (not used)	9	Speaker A
10	Reed 3 (not used)	10	Speaker B

Flachband Lok-Tender Umbau

T1	Bez	T2	Bez
1	Schiene A M1	1	Schiene B M1
2	Schiene A M1	2	Schiene B M1
3	Motor A M1	3	Motor B M1
4	Motor A M1	4	Motor B M1
5	Fire + Front Light	5	Front Light
6	Motor A Ma	6	Motor B M1
7	Fire Minus	7	Cabine
8	Ventilator 1 *	8	GND (Ventilator) *
9	Heizung Plus	9	Speaker A
10	Heizung F	10	Speaker B

* T1.8 und T2.8 auf Platine verbunden => auftrennen !

