

**Betriebsanleitung für:
WP&Y GE-90**

Sounds

Das Soundfile für Ihre Lok ist durch Amerikanische Leute programmiert. Diese haben ein Menge Funktionen eingebaut:

The GE-90 locomotives were equipped with an Alco 6-251 motor. These sounds are taken from a similar loco with this engine.

File also contains an "Isolation Switch" Mode on F15 when Standing Still.


Pressing F15 while not moving will lower the prime mover and lock the motor. F15 must be turned off to begin moving.

Another Mode is "Reverser In Center Position". When pressing F24 while stopped, the motor will lock so you can throttle through the notches like the prototype in neutral. F24 must be turned off to begin moving.

This project has "Run 8" mode. When turning on F26 with F28 off, the prime mover goes to run 8. Turning off F26 returns the prime mover sounds back to normal mode.

This project has "Coast" mode. When turning on F27 with F28 off, the prime mover goes to idle for coasting purposes. Turning off F27 returns the prime mover sounds back to normal mode.

Das generelle Anschluss-Schema sieht so aus (Loksound XL V 5.0):



Ersatzteilen

Alle Teile sind beim Hersteller zu bekommen. Die Verschleißteile wie Bürsten entsprechen den Teilen von Hersteller wie LGB oder Massoth.

Bitte schicken sie ein Email an service@edgb.nl für ihre Bestellung von Verschleißteilen oder Fragen.

Garantie

Die Garantiezeit ist 2 Jahre ab Ablieferungsdatum. Verschleißteile (Bürsten, Motoren, Pantographen) sind hiervon ausgeschlossen.

Alle Werksgarantie verfällt beim selbstständig öffnen von das Modell.

Bitte, bei Reklamationen, wenn immer möglich diese mit Bildern dokumentieren.

Wir wünschen sie viel Spaß mit ihre Modell!

Team Ed's Garten Bahn
www.edgb.nl
info@edgb.nl